

Catwalk[®]

SUPERIOR CAT DOOR



INSTALLATION INSTRUCTIONS FOR MODELS:

W-UCD	Wood Upgradeable Cat Door
W-MCD	Wood Multi-Magnetic Cat Door
W-CD	Wood Cat Door
W-CDT	Wood Cat Door with Tunnel
W-SDD	Wood Small Dog Door
W-SDDT	Wood Small Dog Door with Tunnel

Before installing this cat flap please read the following instructions carefully



Cut along inside line on the template.

Next position template at the appropriate height and tape to door, ensuring the Template is level. We suggest the bottom of the flap is kept level with the cat's stomach where possible. Transfer cut out shape by drawing a pencil line around the cut on to the door or panel



Drill a 3/8" (10mm) hole on the inside edge of the marked cut out.



Cut out the hole using a jig saw by starting at the 3/8" (10mm) drilled hole. Cut the hole by following the marked line on the outside edge.



Slip the external cat door frame (main body), into the hole from the outside. Next slip the internal frame over the main frame. This is a slip joint which allows the frame to be compressed to fit the door thickness.



Drill four 3/16" (4mm) holes through each of the four corners on the internal frame on the door panel. Next remove door components from the door and now open each of the holes to 5/16" (7mm). This will allow sufficient clearance for the fastening screws to be aligned.



Ensure screws provided are cut to the correct length prior to fastening. The correct screw length = (door panel (A) thickness + 1 1/16" (18mm))



$$B = A + 1\frac{1}{16}'' (18\text{MM})$$



Cut screw to length



Replace the inner and outer door frames back into the hole, cut out and fasten together using the screws provided. Cover screws with plastic caps provided.